





PHASE 9-A

 = TO BE PLACED AT ALL DRIVEWAYS IN WORK AREA AT THE SIDE/CORNER OF THE DRIVEWAY WITHOUT ANY OBSTRUCTION OF VIEWS




DETAIL A


200' FT



200' FT




200' FT



SPEEDING FINES DOUBLED WHEN WORKERS PRESENT

200' FT





FLAGGERS MAY BE NEEDED DURING PEAK HOURS TO ASSIST WITH DRIVEWAYS

LEGEND

 = WORK LIMITS

 = CHANNELIZING DEVICE

 = TRAFFIC SIGNAL

 = LANE IDENTIFICATION

 = WATER FILLED BARRIER WALL